

VEERE GRENNY ASSOCIATES
INTERIOR DESIGN & DECORATION

Wallpaper Installation Guidelines.

Walls:

- Walls should be dry and in a sound condition.
- An appropriate grade of lining paper (normally 1000 grade) should be cross-lined / hung horizontally.

Paste / Adhesive:

- We recommend a ready mixed tub adhesive of a light grade (Yellow lid) made by Albany and available from Brewers Decorating Merchants, or Halls Beeline ready mixed vinyl adhesive.
- If you have any doubts about which adhesive to use, a traditional starch-based ready mixed adhesive (Green lid) should be used.
- Self-mix cellulose flake adhesives should be avoided.
- Edges should be well pasted and you must avoid squeezing the adhesive out of the joints.
- No adhesive should be allowed to come into contact with the printed face of the wallpaper.
- Allow sufficient soaking time per sheet until the folded length becomes supple.
- Do not crease the sheet when folding.

Hanging:

- Check each sheet is the correct way up.
- Paste and hang one length at a time.
- Do not get any adhesive on the face of the wallpaper.
- If the rolls come numbered, hang in sequence.

Our wallpapers are traditional hand made pulp papers; block printed using distemper inks. They should always be hung by an experienced wallpaper hanger. Please contact us for the details of our recommended installer.